


Explanation of Symbols

PAGE 5
D200/UEM

- connection goes to
(more components between)







- End of connection
(No more components between)


Table of Contents


Page


DCT4 Common Baseband	1
System Connector & IRDA	2
Audio	3
Camera/LCD Connector	4
UEMK	5
UPP & Memory	6
FM Radio	7
Baseband Connections	8
RF Part	9
Signal Overview	10
Component Finder	11


















Customer Care Europe, Middle East & Africa
SCCE Training Group
© 2004 NMP Only for training and service purposes


CONFIDENTIAL

8(11)

Baseband Connections
RH-20
21.04.2004

Version 2.0 Approved
(PCB) Version_1A0_09





Hi/ low-mode

